


# © 2017 GSLV Mk II 1:96 Scale Instruction Manual







#### Assembly of First Stage (same as PSLV)





























## Adding Second Stage






# Adding the Cryogenic Upper Stage (CUS)
















# Adding the fairing





## **Booster assembly**





































































































#### **Booster Attachments**





































www.axmpaperspacescalemodels.com